

Dräger X-plore® 3300/3500

Donning Procedure



D-7868-2018



D-16563-2018

Position two bayonet filters.



D-16577-2018

Ensure that the line markings on filters and mask line up. Insert the filters in the direction of the arrow until they lock into place.



D-16581-2018

Draw the buckles of the head harness up to the end of the harness. Pull the neck strap through completely until the buckles of the head harness touch the yoke of the half mask.



D-16651-2018

D-16588-2018

Close the clasp (Dräger X-plore® 3500 only). Put the neck strap around your neck.



D-16592-2018

Position the half mask over mouth and nose and place the head harness over the back of your head, with the head harness above your ears.



D-16596-2018

Pull the ends of the straps until the half mask rests tightly against your face.

Before use: Perform a leak test



D-16600-2018

Negative pressure test: Seal both respiratory filters with your hand and breathe in until a negative pressure is created. Hold your breath for a moment. The negative pressure should be maintained. If not, adjust the harness.



D-16747-2018

Positive pressure test: Seal the exhalation valve of the half mask and breathe out forcefully. The half mask must not lift off your face. If the exhaled air dissipates between face and mask body, adjust the harness.



D-16610-2018

Ready for use.