

DIGITAL MINI SCALE

Quick User Guide
Guide d'Utilisation Rapide
Kurze Bedienungsanleitung



ENGLISH

Thank you for purchasing our digital scale. With normal care and proper treatment, this scale will provide years of reliable service.

General Maintenance and Care

1. Avoid exposure to extreme heat or cold. Also avoid any kind of moisture. Always allow your scale to acclimate to normal room temperature before use.
2. Keep your scale in a clean and dry environment. Dust, dirt, moisture, vibration, air currents and proximity to other electronic equipment may have an adverse effect on the accuracy and reliability of the scale.
3. Handle the scale with care. Gently apply all items to be weighed on the tray top. Although this scale is designed to be quite durable, avoid rough treatment, as this may permanently damage the internal parts. Always avoid shaking and dropping. This is a precision instrument and should be handled with extreme care.

Specification and Function

1. Capacity / Accuracy: 100g/0.01g, 200g/0.01g, 600g/0.1g
2. Units: g, oz, ozt, dwt, ct, gn
3. Key function: ON/OFF, TARE, MODE
4. Display: LCD display with backlight
5. Auto off: 180 seconds of inactivity
6. Power: 2 AAA batteries
7. Operation Temp: 0°C to 40°C

Operation

1. Place the scale on a leveled surface & press "ON/OFF" key to turn on the scale or power it off.
2. Wait until the LCD display shows zero, then press "MODE" key to choose the weighing unit.
3. Place the item to be weighed on the surface and wait until the reading is stable.

Tare Function

1. Turn on the scale as described above.
2. Place the "tare item" on the platform. Press "TARE" key and wait until the LCD displays zero.
3. Scale can now be used for weighing. Add the "net-weight-item".

Calibration

1. Place the scale on a leveled surface & power it on.
2. Press and hold the "MODE" key until the display reads "CAL", then release the key.
3. Press the "MODE" key again and the display will show the required calibration weight.
4. Place the weight on the center of the platform. The LCD display will read "PASS" and then return to normal weighing mode. Remove the weight and turn off the scale.

Warning

1. "LO": Low voltage. Please replace the batteries.
2. "EEEE": Over load. Please remove item quickly to protect the scale.